

Ben David

ASSEMBLY INSTRUCTIONS

Product Number: 9313760537466 & 9313760537961

1. Carefully unpack parts from carton, removing all packaging and ensuring all parts are included.
2. .Install the bulb into the socket(B).
4. Add the Shade (D) onto the Harp (C).

BULB DETAILS:

Max lamp rating: 1 x 25 Watt

E14 Edison screw type base.

(BULB NOT INCLUDED)

CARE INSTRUCTION:

Ensure lamp is turned off when replacing bulbs or cleaning. Allow to cool before handling. Only replace bulbs with correct type, rating and size. Do not use harsh abrasives or solvents on any part of the fixture. Clean only using diluted mild detergent on damp cloth. Do not insert any object into lamp holder during cleaning.

NOTE:

- Do not use in the bathroom or damp areas.
- Place the lamp on a flat surface and ensure there are no flammable materials near by.
- This product is for indoor use only.
- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

Imported by:

Kas Australia PtyLtd

www.kasaustralia.com.au

CustomerService:02 93175700

